

# **CONVECTAIR**

## **CALYPSO**

7825



## **Installation & Operating Instruction**

( IMPORTANT : To be read and kept by the user )



## - INTRODUCTION -

Dear owner,

Congratulations on the purchase of this premium electric heater. **CONVECTAIR** develops and produces the highest quality heating product in the electrical industry.

To obtain the best results and the ultimate in performance and comfort, please take a moment to read the installation, operation and maintenance instructions detailed in this manual.


### **WARNING :**

Your heater is already equipped with a precise electronic thermostat. It must not be connected to a wall thermostat

## - TABLE OF CONTENTS -

QUICK START GUIDE.....	PAGE 4
1- SPECIFICATIONS.....	PAGE 5
2- RECOMMENDED SET-UP.....	PAGE 5.6
3- INSTALLATION AND MOUNTING.....	PAGE 6.7
4- ELECTRICAL CONNECTION.....	PAGE 7
5- OPERATING INSTRUCTIONS.....	PAGE 8.9.10
6- OVERHEAT CONTROL.....	PAGE 11
7- MAINTENANCE.....	PAGE 11
8- TROUBLESHOOTING.....	PAGE 12
9- IDENTIFICATION OF YOUR HEATER.....	PAGE 12
10-WARRANTY INFORMATION.....	PAGE 12

- A- On / Standby key**
- B- Temperature setting keys**
- C- Auto programming function 24H**
- D- Timer function**
- E- Backlit LCD screen**
- F- Temperature display**
- G- Locked controls indicator**
- H- Heating indicator symbol**



**Electrical requirements : 240 V - 60 Hz**

See pages 7.

**Installing and connecting the heater :**

See pages 5 ,6 and 7.

**To shut off heater operation:**

Press the  key briefly

**To set the desired temperature :**

Using the + and – keys, you can raise or lower the desired temperature (see page 9)

**Fast heat :**

Turn the heater on.

Press on the  key, the heater will run full power (2000 W) for the duration set on the timer.

**Troubleshooting :**

See page 12.

**To contact Convectair :**

See page 12.

## 1 SPECIFICATIONS

- Your new CALYPSO is a fan-forced heater.
- This heater is equipped with 2 heat levels : 1000 W regulated with the electronic thermostat and 2000 W fast heat on demand.
- Minimum obstruction and designed to heat your room quietly, consistent heat, it is a perfect heater for your bathroom or other intermittently-used rooms.
- Your CALYPSO can be used with the optional **CONVECTAIR** Programmer Module (pilot wire) allowing scheduled temperature set-backs in periods of prolonged absence providing the same comfort and more savings.


**READ CAREFULLY** :These instructions are essential to install and use your new CALYPSO safely.

Model	Total Power	Regulated power	Forced power	Width (inch)	Height (inch)	Depth (inch)	Weight (lb)
7825-C20	2000 W	1000 W	2000 W	12 1/4" (310 mm)	16 1/8" (410 mm)	6" (150 mm)	11,9 (5,4 kg)

## 2 RECOMMENDED SET-UP

- Your heater must be installed in accordance with national and local codes and **CONVECTAIR** recommends an installation by a qualified electrician.
- Your heater must be installed so that the control panel is out of reach from anyone in the bath-tub or in the shower. Do not install over a bath-tub or spa.
- Do not install the heater behind a door, furniture or others obstacles, or in front of an air exhaust vent. Keep combustible materials such as curtains, away from the heater.
- Your heater is equipped with a heating element that may reach high temperatures. Do not install or operate in the presence of gasoline, paint solvents or other flammable products.
- Maintain the minimum required clearances (height from floor, distances from side walls or furniture, drapes, etc...)(Fig. 3).

«CAUTION : DO NOT INSTALL BOTTOM AT LESS THAN 10" (255 mm) FROM THE FLOOR, SIDES AT LESS THAN 4" (100 mm) AND TOP MORE THAN 12" ( 300 mm )FROM ANY SURFACES»




### 3 INSTALLATION AND MOUNTING

#### - Wall bracket installation:

- Remove the wall bracket from the heater by pushing the 2 clipping tabs (Rep. A).
- Place the wall bracket on the wall and mark the 4 mounting holes in accordance with the dimensions shown in figure 2.
- Fix the wall bracket with at least 4 screws ( $\varnothing$  5.5 max) ensuring the bracket is in the right orientation and at the correct installation height.
- **NOTA 1** : Be sure to respect the distances reported in Figure 4.
- **NOTA 2** : The device must be fixed to its support, the use of adhesive to fix the support or the device is forbidden.

#### - Heater installation:

- To mount the unit on the wall bracket, engage the lower legs into the slots at the bottom and back of the heater. This operation is facilitated by presenting the unit slightly tilted forward.
- Clip the top of the wall bracket.



## 4 ELECTRICAL CONNECTION

- **CONVECTAIR** recommends that your heater be installed by a qualified electrician and in accordance with national and local codes.
- This heater must be connected to a 240 Volt (60 cycles) circuit. Disconnect the power supply before making wiring connections to prevent electrical shock and equipment damage. If you are using a programmer system, make sur to cut the power off ALL electrical heating circuits in the home



- To prevent short circuits and electrical shocks turn the power off at the main panel before attempting the installation or making any repairs.
- If the power cable is damaged it must be replaced by the manufacturer, an approved service depot or a technician with similar qualifications to avoid any danger.

### - RESPECT WIRE COLOR WIRING

WITH the use of pilot wire (PW)





WITHOUT the use of pilot wire (PW)

CANADA

USA

CANADA

USA



P = PURPLE R = RED B = BLACK G = GREEN C = COPPER W = WHITE PW : PILOTE WIRE

- Disconnect power to this unit and to all units connected to the pilot wire before opening.
- Grounding the pilot wire ( purple wire ) will cause severe damage to internal circuits.
- Never connect pilot wire ( purple wire ) to electrical supply.
- You must connect the ground wire of the heater (green wire) with the copper wire.
- The purple wire with the seal at the extremity should not be used for the electrical connection.
- The purple wire is used only if the heater is connected with the **CONVECTAIR** central programming system.
- Fix the unit on the wall bracket before turning the power back on.

## 5 OPERATING INSTRUCTIONS

- A- ON / Standby key
- B- Temperature setting keys
- C- Auto programming function 24H
- D- Timer function
- E- Backlit LCD screen
- F- Temperature display
- G- Locked controls indicator
- H- Heating indicator symbol



### - To turn the heater ON

Press on the  key on the control panel.

The screen turns on, the button turns green, your device is running.

### - To shut off heater operation

Press on the  key on the control panel.

The green light turns orange, the screen turns off, the heater is in standby

### - To set the desired temperature

Using the + and – keys, you can raise or lower the desired temperature as you wish by 1°F (0.5°C) each time the key is pressed, between 45°F and 82°F (7°C and 28°C).

### - To change display in °C or °F

Shut off the heater operation. Simultaneously press keys «  » and «+» and hold for 3 seconds to switch display in °C (Celsius) or °F (Fahrenheit).

### - The «Timer » function

This function allows an immediate and additional 1000 W of heat during a time determined period(from 5 to 90 minutes). So you are using your device in its full power unregulated, ie: 2000 W .

### - To use the «Timer » function

Pressing the «  » button triggers the «Timer » function for a period of 15 min (default). The red indicator lights. Successive presses on «-» and «+» allow to modify the duration between 5 and 90 min in steps of 5 min. Hold the «  » key for 3 seconds to select the new default duration.

### - To stop the « Timer » function

The «Timer » function stops automatically once the time has elapsed, or by pressing on the «  » to stop the function (the red indicator turns off, the display shows the desired temperature).

### - To lock the controls

This function locks any manipulation of the thermostat to prevent tampering, particularly by children. Only the «Timer » function can be activated.

Press simultaneously for 3 seconds the «  » and «+» keys to activate this function. The display shows «  » indicating the control panel is locked.

### - To unlock the controls

To unlock the control panel, press again simultaneously for 3 seconds the «  » and «+» keys. The lock symbol «  » is no longer displayed.

### - To activate and set the « Auto Cycle 24H »

You enter every day at the same time in your bathroom and you like to have this feeling of warmth. The « Auto Cycle 24H » is handled automatically by setting the «Chrono» time.

### - To set the « Chrono » time

- The « Chrono » time is the time at which you want the bathroom to be warm every day.
- Press on the « 24H » key. The light indicator stays on and the function is activated.
- To disable it, use the same procedure (pressing the « 24H » key).
- If no « Chrono » time is set when the command is activated, the indicator flashes, indicating that the « Auto Cycle 24H » cannot be activated.
- To set the « Chrono » time, press 3 seconds on the « 24H » key. This causes a slow blink of the « 24H » light indicator for 3 seconds, thus validating the actual time as the « Chrono » time.
- If the « Auto Cycle 24H » is activated, the device will do a preheat of 15 minutes on regulated power, then another 15 minutes on full power before the « Chrono » time. At this time, it activates the timer for the duration saved by default.
- IN CASE OF POWER FAILURE, ALL SETTINGS WILL BE LOST.

## **Recommendations and advices**

### **CAUTION:**

This device is intended for drying towels. Do not introduce anything in the unit.  
The first time your CONVECTAIR heater is used, a light smoke could be released.  
This is normal and should disappear after about 2 to 3 minutes.

### **CAUTION: DO NOT COVER**

If the heater is covered, there is a risk of overheating. It is forbidden to cover or obstruct the air inlet or air outlet at the risk of incidents or damage to the unit.

## 6 OVERHEAT CONTROL

This heater is equipped with separate overheat control for the heating element. In case of a malfunction of the unit (blocked air output or intake, for example) the heater will stop heating automatically. After correcting the malfunction the heater can be reset.

### **To reset the heater :**

Turn the heater Off. Check that the lower back inlet and the lower front outlet are free of obstruction. Wait 5 minutes and turn the heater back on.

## 7 MAINTENANCE

To keep your **CONVECTAIR** unit clean, regular maintenance is suggested. To remove dust, use a soft cloth. To remove a stain, use a damp cloth.

For a better performance and maximum efficiency, it is suggested that dust and lint be regularly removed from the protective grill situated in front of your CALYPSO.

**NEVER USE ABRASIVE OR ACETONE-BASED PRODUCTS TO CLEAN YOUR HEATER AS THIS MAY DETERIORATE THE EPOXY FINISH.**

**ANY REPAIR ON YOUR CONVECTAIR HEATER SHOULD ONLY BE DONE BY A QUALIFIED TECHNICIAN, AND ONLY AFTER HEATER HAS BEEN DISCONNECTED.**

### **Recommendations and advice**

Your **CONVECTAIR** heater will become hot when in use. Caution is advised when young children are present.

Do not insert small objects in the heater : this could cause an electrical short circuit, fire or damage to the inner components.

Any use or modifications not approved by **CONVECTAIR** may cause electrical short circuits, fire or injuries to the users.

In certain cases, it is possible for yellowing of the surface to occur over time.

This is not due to a manufacturing defect. This is caused by surrounding air, which may contain smoke or dust, being heated and circulated through the heater.

**Prevention : it is suggested that surfaces be frequently cleaned especially with units installed in locations where cigarette smoke is present or in the kitchen. Never use this heater during construction work or other activities that generate a lot of dust.**

The first time your **CONVECTAIR** heats, a light smoke could be released. This is normal and should disappear after about 2 to 3 minutes.

## 8 TROUBLESHOOTING

Before calling your electrician, please go through these simple checks :

- 1- Make sure the breaker in the distribution panel is in the «ON» position.
- 2- Check that the ON /Standby key is green.
- 3- Activate the timer function.
- 4- If no heat is emitted, check the overheat protection (see section 6).
- 5- If the light is still off, and no heat is generated, call CONVECTAIR or the nearest **CONVECTAIR** service center.

## 9 IDENTIFICATION OF YOUR HEATER

**IMPORTANT : PRODUCT INFORMATION APPEARS ON THE HEATER'S IDENTIFICATION LABEL.**

The identification label is located on the inside of the heater

It includes :

- The complete model number and its production reference number (A) that must be included in any warranty claim.
- Capacity (B).
- Standard certification (C).



## 10 WARRANTY INFORMATION

**2 years against all defects / 5 years on heating element.**

All **CONVECTAIR** heaters are subjects to a double warranty : 2 years on all parts and manufacturing defects and 5 years on the heating element itself.

Warranty is applicable from date of purchase by the customer and under certain specific conditions. All details furnished with each heater. Please keep your invoices (purchase and / or installation).

### SERVICE CENTERS :

Contact **CONVECTAIR** to find closest service center:

- Toll-free : 1 800 463-6478
- Website : [www.convectair.com](http://www.convectair.com)

# CONVECTAIR

30, carré Sicard, Sainte-Thérèse, Qc, CANADA J7E 3X6  
Phone : (450) 433-5701 Fax : (450) 434-3166  
Email : [support@convectair.com](mailto:support@convectair.com)  
[www.convectair.com](http://www.convectair.com)